





IT INFRASTRUCTURE AND COMPUTER NETWORKS



Week 8

Packets travelling within the network


Switch is **switching packets** between source and destination devices



Problem with Switching




How do packets travel between different networks?



What is Routing?

Routing is the process of **selecting path** from sender to receiver


Router uses **Routing Table** to forward packets to the **Next Hop device**



How does a Router work?

To forward packets Router uses:

1. Interfaces: Each interface is a **separate network**
Only **one interface** can be connected to **the same network**
2. Routing Table: Tells **where to send** packets (destination network and next hop)
Built manually and automatically



Routing Table


Routing table is built:

Statically (manually)


- Fixed Route
- Easy to set up, straightforward
- Requires manual updates when topology is changed
- Not adaptable

Dynamically (automatically)


- Routes are learnt through dynamic protocols
- Routes are chosen based on metrics such as distance, cost, or speed
- Adaptable in large/changing networks



Directly connected networks and interface IP-addresses are filled in the Routing Table of the router automatically



What about not directly connected networks?



Static Routing Configuration

To add static route to network 172.31.120.0/24 in Router0 :

```
Router(config)#ip route 172.31.120.0 255.255.255.0 10.10.1.2
```

To see Routing Table: Router#show ip route


```
Router#show ip route
Codes: L - local, C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
       i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
       * - candidate default, U - per-user static route, o - ODR
       P - periodic downloaded static route
```

Gateway of last resort is not set


```
    10.0.0.0/8 is variably subnetted, 2 subnets, 2 masks
C       10.10.1.0/30 is directly connected, GigabitEthernet0/2
L       10.10.1.1/32 is directly connected, GigabitEthernet0/2
    172.16.0.0/16 is variably subnetted, 2 subnets, 2 masks
C       172.16.35.0/24 is directly connected, GigabitEthernet0/0
L       172.16.35.1/32 is directly connected, GigabitEthernet0/0
S       172.31.0.0/24 is subnetted, 1 subnets
S       172.31.120.0/24 [1/0] via 10.10.1.2
    192.168.13.0/24 is variably subnetted, 2 subnets, 2 masks
C       192.168.13.0/24 is directly connected, GigabitEthernet0/1
L       192.168.13.1/32 is directly connected, GigabitEthernet0/1
```

Static route is added


S (Static) - manually configured route



Example of Static routing configuration



5 networks



Configure PCs:

PC0

192.168.1.254

255.255.255.0

192.168.1.1

PC1

172.16.2.126

255.255.255.128

172.16.2.1

PC2

10.10.3.62

255.255.255.192

10.10.3.1

Configure Routers:

```
Router(config)#int g0/0
Router(config-if)#ip ad 192.168.1.1 255.255.255.0
Router(config-if)#no sh

Router(config-if)#
%LINK-5-CHANGED: Interface GigabitEthernet0/0, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/0, changed state to up

Router(config-if)#int g0/1
Router(config-if)#ip ad 10.10.10.1 255.255.255.252
Router(config-if)#no sh

Router(config-if)#
%LINK-5-CHANGED: Interface GigabitEthernet0/1, changed state to up
```


Assign IP address, subnet mask and default gateway for each PC

Assign IP address and subnet mask for each Router's interfaces.

Don't forget to turn on interfaces.

```
Router(config)#ip route 192.168.1.0 255.255.255.0 10.10.10.1
Router(config)#ip route 10.10.3.0 255.255.255.192 10.10.10.6
```


If you want to reach 192.168.1.0/24 network, ask 10.10.10.1



Router1 knows only about its direct neighbours: RT0 and RT2; and only about directly connected networks: 172.16.2.0/24, 10.10.10.0/30 and 10.10.10.4/30



```
Router(config)#ip route 0.0.0.0 0.0.0.0 10.10.10.2
```

If you want to reach ANY network, ask 10.10.10.2



Router0 knows only
about RT1

What if we add 2 more networks?




Inconvenient

Slow

Easy to make a mistake


Dynamic routing

Dynamic routing is a networking technique where routers automatically learn network topology and update routing tables in real-time, enabling adaptation to changes such as link failures or traffic congestion.




OSPF


Open Shortest Path First (OSPF) is a link-state routing protocol used to find the best path between routers.




The Router ID





Becoming Neighbors




Exchanging Database Information








The SPF Algorithm



OSPF configuration



Step 1: Create OSPF process

```
| Router(config)#router ospf 1
```

Step 2: Assign router-id


```
| Router(config-router)#router-id 1.1.1.1  
| Router(config-router)#ex
```

Step 3: Configure directly connected networks

```
| Router(config-router)#network 192.168.1.0 0.0.0.255 area 0  
| Router(config-router)#network 10.10.10.0 0.0.0.3 area 0
```

Network address

Wildcard mask



Wildcard mask

A **wildcard mask** is a 32-bit binary mask used in networking to determine which bits of an IP address to check or ignore when filtering traffic or defining networks. It is often called an **inverted subnet mask**, where 0 bits mean "must match" and 1 bits mean "ignore" (don't care).

255.255.255.0 → 0.0.0.255

255.255.224.0 → 0.0.31.255

Any questions?

